











































































































































Originale	Sostituto	Originale	Sostituto
 Power	 Power	 P +	 Ch +
 1	 1	 P -	 Ch -
 2	 2	 Vol+	 Vol +
 3	 3	 Vol-	 Vol -
 4	 4	 Mute	 Mute
 5	 5	 Source Power	 AV
 6	 6	 Return	 Back
 7	 7	 Home	 Menu
 8	 8	 Up	 Up
 9	 9	 Down	 Down
 0	 0	 Right	 Right
 PC	 Pre Ch	 Left	 Left
 [i+]	 Info	 Enter	 Ok
 Split Screen	 Options	 Exit	 Exit
 Split Screen Swap	 3D	 EPG / DVD Top Menu / Guide	 Guide
 PIP Swap	 Shift + Back	 Red/Rec	 Red
 Tv/DTV	 TV/R	 Green/Pause	 Green





































































Originale	Sostituto	Originale	Sostituto
 Power	 Power	 Down	 Down
 1	 1	 Right	 Right
 2	 2	 Left	 Left
 3	 3	 Enter	 Ok
 4	 4	 Menu	 Menu
 5	 5	 DVD Top	 D. Menu
 6	 6	 Return	 Back
 7	 7	 Play	 Play
 8	 8	 Stop	 Stop
 9	 9	 Pause	 Pause
 0	 0	 >>	 >>
 PC	 Pre Ch	 <<	 <<
 Source Power	 AV	 >>	 >>
 Mute	 Mute	 <<	 <<
 Vol +	 Vol +	 Input 1	 Shift + 1
 Vol -	 Vol -	 Input 2	 Shift + 2
 Up	 Up	 Input 3	 Shift + 3






































Originale		Sostituto		Originale		Sostituto	
	Power		Power		P +		Ch +
	Source Power		AV		P -		Ch -
	1		1		Menu		Menu
	2		2		Exit		Exit
	3		3		DVD Top Menu		D. Menu
	4		4		Up		Up
	5		5		Down		Down
	6		6		Right		Right
	7		7		Left		Left
	8		8		Enter		Ok
	9		9		Input 1		Shift + 1
	0		0		Input 2		Shift + 2
	PC		Pre Ch		Input 3		Shift + 3
	[i+]		Info		Input 4		Shift + 4
	Mute		Mute		Input 5		Shift + 5
	Vol +		Vol +				
	Vol -		Vol -				





Originale	Sostituto	Originale	Sostituto
	Power		Mute
	Source Power		Mute
	AV		Play
	1		Play
	2		Stop
	3		Pause
	4		Rec
	5		>>
	6		<<
	7		Shift + 1
	8		Shift + 2
	9		Shift + 3
	0		Shift + 4
	PC		Shift + 5
	Pre Ch		
	Vol+		
	Vol-		
	Ch +		
	Ch -		

