

























































































































































Originale	Sostituto	Originale	Sostituto
 Power	 Power	 P +	 CH+ / Page+
 1	 1	 P -	 CH- / Page-
 2	 2	 Menu / DVD	 Menu / Home
 3	 3	 Exit / Back	 Exit / Cancel / Clear
 4	 4	 Up	 Up
 5	 5	 Down	 Down
 6	 6	 Left	 Left
 7	 7	 Right	 Right
 8	 8	 OK	 OK
 9	 9	 Guide / Top Menu	 D.Menu / Top
 0	 0	 Guide / Top Menu	 Shift + D.Menu / Top Menu
 DVD RTN	 Shift + 2	 TV Fav/Radio / Setup	 TV/Radio /
 Input	 AV / Input / RDS	 TV Fav/Radio / Setup	 Shift + TV/Radio / Program
 Audio A/D	 Audio / Lang I/II	 Red	 Red / Netflix / Search
 Mute	 Mute / Dimmer	 Green	 Green / APP / Repeat
 Vol +	 Vol+	 Yellow	 Yellow / YouTube / Repeat
 Vol -	 Vol-	 Blue	 Blue / Prime Video / Random

Originale	Sostituto	Originale	Sostituto
 P +	 CH+ / Page+	 P -	 CH- / Page-
 Menu / DVD	 Menu / Home	 Exit / Back	 Exit / Cancel / Clear
 Up	 Up	 Down	 Down
 Left	 Left	 Right	 Right
 OK	 OK	 Guide / Top Menu	 D.Menu / Top
 Guide / Top Menu	 Shift + D.Menu / Top Menu	 TV Fav/Radio / Setup	 TV/Radio /
 TV Fav/Radio / Setup	 Shift + TV/Radio / Program	 Red	 Red / Netflix / Search
 Green	 Green / APP / Repeat	 Yellow	 Yellow / YouTube / Repeat
 Blue	 Blue / Prime Video / Random		





Originale		Sostituto		Originale		Sostituto	
	Power		Power		Up		Up
	1		1		Left		Left
	2		2		OK		OK
	3		3		Right		Right
	4		4		Top Menu		D.Menu / Top
	5		5		Down		Down
	6		6		Set Up		Setup / OPT /
	7		7		[<>]		Picture / Format
	8		8		→ / ←		Display / Media
	9		9		[i+]/[≡i]		Info / Angle
	0		0		Text/Audio		Text / Goto
	Input		AV / Input / RDS		Open/Close/Subtit		Eject / Surround
	Vol+		Vol+		Stop/O /I		Stop / Hold
	Vol-		Vol-		Play/[≡o]		Play / Slow
	Mute		Mute / Dimmer		Pause/Step/[▽]		Pause / Step / Freeze
	Menu/DVD		Menu / Home		I<</[≡?]		I<< / Preset-
	Exit / Back		Exit / Cancel / Clear		<</[≡+]		<< / Tune-



