





































Originale	Sostituto
	Power
	Info
	Mute
	1
	2
	3
	4
	5
	6
	7
	8
	9
	Source
	0
	Audio I/II
	Menu
	Exit



































Originale	Sostituto
	Up
	Left
	Enter
	Right
	Down
	CH +
	Index
	Vol +
	CH -
	List
	Vol -
	Fav
	Sleep
	EPG
	Recall
	Red / <<
	Red / <<













































Originale	Sostituto
	 Power
	 Info / Angle
	 Mute / Dimmer
	 1
	 2
	 3
	 4
	 5
	 6
	 7
	 8
	 9
	 AV / Input / RDS
	 0
	 Audio / Lang I/II
	 Menu / Home
	 Exit / Cancel / Clear

Originale	Sostituto
	 Up
	 Left
	 OK
	 Right
	 Down
	 CH+ / Page+
	 Display / Media
	 Vol+
	 CH- / Page-
	 Smart / List
	 Vol-
	 Fav / Marker / PC
	 Sleep / Timer
	 Guide / EPG / -/-
	 Back / Return
	 Red / Netflix / Search
	 <<
	 << / Tune-



