







































































Originale		Sostituto		Originale		Sostituto	
	Power		Power		FAV		Pre Ch
	Source		AV		Setup		Options
	Light		Media		Menu		Menu
	Text		Text		Exit		Exit
	[≡?]/SUB-T		Subt		Up		Up
	[≡o]/Audio		Dual		Down		Down
	[≡i]/EPG		Guide		Right		Right
	[≡x]/Sat.List		List		Left		Left
	[≡♦]/IPI		Format		OK		Ok
	<<		<<		Vol+		Vol +
	Play		Play		Vol-		Vol -
	Pause		Pause		Mute		Mute
	>>		>>		Info		Info
	I<<		I<<		P+		Ch +
	Stop		Stop		P-		Ch -
	Rec		Rec		Red/Radio		Red
	>>I		>>I		Green/Sleep		Green



