







































































Originale		Sostituto		Originale		Sostituto	
	Power		Power		8		8
	Freeze		Pause		9		9
	Subtitle		Subt		0		0
	Guide		Guide		Jump		Back
	Fav.CH		Pre Ch		ENT		Smart
	I-II		Dual		Vol +		Vol +
	Text / Mix		Text		Vol -		Vol -
	Mute		Mute		Info		Info
	Sleep		Sleep		Input		AV
	P.Size		Format		CH +		Ch +
	1		1		CH -		Ch -
	2		2		Exit		Exit
	3		3		Menu		Menu
	4		4		P.Mode		Shift + Format
	5		5		S.Mode		Shift + Dual
	6		6		Up		Up
	7		7		Right		Right



