









































































































































































Originale	Sostituto	Originale	Sostituto
 Power	 Power	 Q.View	 D. Menu
 Tv/Rad	 TV/R	 Vol+	 Vol +
 Subtitle	 Subt	 Vol-	 Vol -
 AD/PIP/*	 Dual	 Mute	 Mute
 Tv/PC	 Media	 FAV	 Pre Ch
 Input	 AV	 Guide	 Guide
 1	 1	 P+	 Ch +
 2	 2	 P-	 Ch -
 3	 3	 Text	 Text
 4	 4	 Info	 Info
 5	 5	 T.Opt	 Shift + Options
 6	 6	 Q.Menu	 Menu
 7	 7	 Back	 Back
 8	 8	 Settings	 Options
 9	 9	 Exit	 Exit
 0	 0	 Up	 Up
 List	 List	 Down	 Down

Originale	Sostituto	Originale	Sostituto
 MUTE	 MUTE	 SHIFT	 SHIFT
 TV	 TV	 DVD	 DVD
 SAT	 SAT	 AUX	 AUX
 PLAY MODE	 PLAY MODE	 REC MODE	 REC MODE
 Play	 Play	 Pause	 Pause
 Stop	 Stop	 FF	 FF
 RR	 RR	 Still	 Still
 Left	 Left	 Right	 Right
 DISC NAV	 DISC NAV	 SOUND	 SOUND
 LIST	 LIST	 AD	 AD
 PROG	 PROG	 SETTINGS	 SETTINGS
 SEARCH	 SEARCH	 DUAL	 DUAL
 PICTURE	 PICTURE	 SUBT	 SUBT
 ECO	 ECO	 OPT	 OPT
 E-MANUAL	 E-MANUAL	 3D	 3D
 REPEAT	 REPEAT	 TIMER	 TIMER
 ZOOM	 ZOOM	 AV	 AV
 D.MENU	 D.MENU	 TOP MENU	 TOP MENU
 TEXT	 TEXT	 DISPLAY	 DISPLAY
 MUTE	 MUTE	 MENU	 MENU
 GUIDE	 GUIDE	 INFO	 INFO
 P+	 P+	 OK	 OK
 P-	 P-	 Left	 Left
 TEXT	 TEXT	 Right	 Right
 REPEAT	 REPEAT	 Down	 Down
 TEXT	 TEXT	 CLEAR	 CLEAR
 INFO	 INFO	 EXIT	 EXIT
 T.Opt	 T.Opt	 RETURN	 RETURN
 Q.Menu	 Q.Menu	 BACK	 BACK
 BACK	 BACK	 HOME	 HOME
 Settings	 Settings	 SMART	 SMART
 EXIT	 EXIT	 APP	 APP
 Up	 Up	 MEDIA	 MEDIA
 Down	 Down	 CH+	 CH+
 Up	 Up	 CH-	 CH-
 Down	 Down	 1	 1
 Up	 Up	 2	 2
 Down	 Down	 3	 3
 Up	 Up	 4	 4
 Down	 Down	 5	 5
 Up	 Up	 6	 6
 Down	 Down	 7	 7
 Up	 Up	 8	 8
 Down	 Down	 9	 9
 Up	 Up	 0	 0
 Down	 Down	 FAV	 FAV
Up	Up	 GUIDE	 GUIDE
Down	Down	 PRE-CH	 PRE-CH



