




































































Originale	Sostituto
 Power	 Power
 TV	 Guide
 Rec	 Rec
 I<<	 I<<
 Red	 Red
 Green/[]	 Green
 Stop	 Stop
 Play	 Play
 Yellow / List	 Yellow
 >>I	 >>I
 PIP []	 Blue
 AV/[?]	 AV
 I-II/[≡≡]	 Dual
 [<>]/[+]	 Format
 [-O-]	 Exit
 Menu	 Menu
 [=]	 Text

Originale	Sostituto
 Pause	 Pause
 Up	 Up
 Left	 Left
 OK	 Ok
 Right	 Right
 Down	 Down
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 Smart J	 Smart
 Smart []	 Media
 P+	 Ch +
 P-	 Ch -
 1	 1
 2	 2
 3	 3
 4	 4





Originale	Sostituto
 Power	 Power
 O	 Guide
 Rec	 Rec
 I<<	 I<<
 Red	 Red
 Green/[[]]	 Green
 Stop	 Stop
 Play	 Play
 Yellow / List	 Yellow
 PIP [■]	 Blue
 >>I	 >>I
 AV/[?]	 AV
 I-II/[≡≡]	 Dual
 [<>]/[+]	 Format
 -O-	 Exit
 Menu	 Menu
 Pause	 Pause

Originale	Sostituto
 [≡]	 Text
 Up	 Up
 Left	 Left
 OK	 Ok
 Right	 Right
 Down	 Down
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 Smart ♪	 Smart
 Smart []	 Media
 P+	 Ch +
 P-	 Ch -
 1	 1
 2	 2
 3	 3
 4	 4





Originale	Sostituto	Originale	Sostituto
 Power	 Power	 Smart J	 Smart
 I<<	 I<<	 Smart []	 Media
 >>I	 >>I	 P+	 Ch +
 AV/[?]	 AV	 P-	 Ch -
 I-II[≡ ≡]	 Dual	 1	 1
 I-III[<>]/[+]	 Format	 2	 2
 -O-	 Exit	 3	 3
 Pause	 Pause	 4	 4
 [≡]	 Text	 5	 5
 Up	 Up	 6	 6
 Left	 Left	 7	 7
 OK	 Ok	 8	 8
 Right	 Right	 9	 9
 Down	 Down	 0	 0
 Vol+	 Vol +	 P<P	 Pre Ch
 Vol-	 Vol -		
 Mute	 Mute		

