




































































Originale	Sostituto
 System Standby	 Power
 Muting	 Mute
 Menu	 Menu
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0 / 10	 0
 Display	 Info
 2 CH	 Red
 AFD	 Green
 Movie	 Yellow

Originale	Sostituto
 Music	 Blue
 Master Vol +	 Vol +
 Master Vol -	 Vol -
 >>I / Preset +	 >>I
 I<< / Preset -	 I<<
 Up	 Up
 Left	 Left
 OK	 Ok
 Right	 Right
 Down	 Down
 Sleep	 Sleep
 FM Mode	 Smart
 Enter / Memory	 Media
 Auto Cal	 Options
 << / Tuning -	 <<
 >> / Tuning +	 >>
 D.Tuning	 Text



















Originale	Sostituto
 Power	 Power
 Power AV	 +  Shift + Power
 Auto Cal	 Smart
 Sleep	 Sleep
 2CH	 Red
 A.F.D.	 Green
 Movie	 Yellow
 Music	 Blue
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9

Originale	Sostituto
 0/10	 0
 -/-->10	 Guide
 Enter/Memory	 Pre Ch
 Menu	 Menu
 DVD Menu	 D. Menu
 Return/Exit	 Exit
 Tools	 Options
 Display	 Info
 D.Tuning/D.Skip	 Dual
 FM Mode	 AV
 Muting	 Mute
 Vol+	 Vol +
 Vol-	 Vol -
 OK	 Ok
 Up	 Up
 Down	 Down
 Right	 Right







































Originale	Sostituto
	 Left
	 Play
	 Pause
	 Stop
	 <</Tuning-
	 >>/Tuning+
	 >>I/Preset+
	 I<</Preset-
	 ←/Replay
	 →/Advance
	 Media
	 +  Shift + Media
	 +  Shift + Dual
	 +  Shift + Pre Ch
	 +  Shift + 1
	 +  Shift + 2
	 +  Shift + 3

Originale	Sostituto
	 +  Shift + 4
	 +  Shift + 5
	 +  Shift + 6
	 +  Shift + 7
	 +  Shift + 8
	 +  Shift + 9
	 +  Shift + 0
	 3D
	 +  Shift + Ok
	 +  Shift + Up
	 +  Shift + Down
	 +  Shift + Right
	 +  Shift + Left
	 +  Shift + Ch -
	 +  Shift + Ch +
	 Text
	+ Shift + AV






Originale	Sostituto
 Power	 Power
 Play	 Play
 Stop	 Stop
 Auto Cal	 Smart
 Sleep	 Sleep
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0/10	 0
 >10* CLEAR	 Guide
 OK	 Ok

Originale	Sostituto
 Enter/Memory	 Pre Ch
 Menu	 Menu
 Display	 Shift + Info
 Muting	 Mute
 Vol+	 Vol +
 Vol-	 Vol -
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 FM Mode	 AV
 2CH	 Red
 A.F.D.	 Green
 Movie	 Yellow
 Music	 Blue
 Pause	 Pause
 >>/Tuning+	 >>





Originale	Sostituto
 Power	 Power
 Power AV	 +  Shift + Power
 Auto Cal	 Smart
 Sleep	 Sleep
 A.F.D.	 Green
 Movie	 Yellow
 Music	 Blue
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0/10	 0

Originale	Sostituto
 -/-->10	 +  Shift + Guide
 Enter/Memory	 Pre Ch
 FM Mode	 AV
 Display	 +  Shift + Info
 Muting	 Mute
 Vol+	 Vol +
 Vol-	 Vol -
 Menu	 Menu
 OK	 Ok
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 Play	 Play
 Pause	 Pause
 Stop	 Stop
 <</Tuning-	 <<



