







































































Originale		Sostituto		Originale		Sostituto	
	Power		Power		:≡		Options
	Home		Smart		Up		Up
	1		1		Down		Down
	2		2		Right		Right
	3		3		Left		Left
	4		4		OK		Ok
	5		5		Stop		Stop
	6		6		Play		Play
	7		7		Pause		Pause
	8		8		Eject		Eject
	9		9		I<		I<<
	0		0		<<		<<
	Subtitle		Subt		>>		>>
	Audio		Dual		>I		>>I
	Pop-Up Menu/Disc Menu		D. Menu		Red		Red
	Top Menu		Menu		Green		Green
	Back		Back		Yellow		Yellow



