



























































Originale	Sostituto	Originale	Sostituto
 Power	 Power	 Up	 Up
 D/A Tv	 Smart	 Down	 Down
 Input	 AV	 Right	 Right
 Guide	 Guide	 Left	 Left
 Radio	 TV/R	 OK	 Ok
 Subtitle/*	 Subt	 Red	 Red
 PIP PR-	 Shift + Ch +	 Green	 Green
 PIP PR+	 Shift + Ch -	 Yellow	 Yellow
 Swap	 Media	 Blue	 Blue
 PIP Input	 Shift + AV	 Vol+	 Vol +
 PIP	 Shift + 3D	 Vol-	 Vol -
 Info	 Info	 Mute	 Mute
 Back	 Back	 FAV	 Pre Ch
 ARC	 3D	 CH+	 Ch +
 Menu	 Menu	 CH-	 Ch -
 Text	 Text	 1	 1
 Exit	 Exit	 2	 2

Originale	Sostituto	Originale	Sostituto
 Power	 Power	 Up	 Up
 D/A Tv	 Smart	 Down	 Down
 Input	 AV	 Right	 Right
 Guide	 Guide	 Left	 Left
 Radio	 TV/R	 OK	 Ok
 Subtitle/*	 Subt	 Red	 Red
 PIP PR-	 Shift + Ch +	 Green	 Green
 PIP PR+	 Shift + Ch -	 Yellow	 Yellow
 Swap	 Media	 Blue	 Blue
 PIP Input	 Shift + AV	 Vol+	 Vol +
 PIP	 Shift + 3D	 Vol-	 Vol -
 Info	 Info	 Mute	 Mute
 Back	 Back	 FAV	 Pre Ch
 ARC	 3D	 CH+	 Ch +
 Menu	 Menu	 CH-	 Ch -
 Text	 Text	 1	 1
 Exit	 Exit	 2	 2





Originale	Sostituto
	
	
	
	
	
	
	
	
	
	
	
	
	
	
	
	
	

Originale	Sostituto
	













































Originale	Sostituto
Power	Power
Menu	Menu
Up	Up
OK	Ok
Down	Down
Right	Right
Left	Left
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0

Originale	Sostituto
Play	Play
Pause	Pause
Stop	Stop
<<	<<
>>	>>
I<<	I<<
>>I	>>I





Originale	Sostituto
 Power	 Power
 Input	 AV
 CH+	 Ch +
 CH-	 Ch -
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Play	 Play
 Pause	 Pause
 Stop	 Stop

Originale	Sostituto
 Rec	 Rec
 <<	 <<
 >>	 >>

