





















































Originale		Sostituto		Originale		Sostituto	
	Power		Power		4		4
	Mute		Mute		5		5
	DTV / Radio		TV/R		6		6
	Senseye		Smart		7		7
	Backlight		Media		8		8
	Info		Info		9		9
	TV Audio		Dual		0		0
	ATV/DTV		Shift + TV/R		AVC		Shift + AV
	Sleep		Sleep		Return		Shift + Back
	Sound		Shift + Dual		Vol +		Vol +
	Picture		Shift + Format		Vol -		Vol -
	Freeze		Pause		Guide		Guide
	Subtitle		Subt		List		List
	Wide		Format		Prog +		Ch +
	1		1		Prog -		Ch -
	2		2		Back		Back
	3		3		Favorite		Pre Ch





Originale	Sostituto
 Up	 Up
 Left	 Left
 OK	 Ok
 Right	 Right
 Down	 Down
 Input	 AV
 Menu	 Menu
 Hold	 Stop
 Update	 Exit
 Subcode	 Shift + Subt
 Text / Mix	 Text
 Index	 Shift + Info
 [=...]/ List	 Shift + List
 Size	 Eject
 Reveal	 D. Menu
 Red	 Red
 Green	 Green

Originale	Sostituto
 Yellow	 Yellow
 Blue	 Blue

