







































































Originale	Sostituto
 TV	 TV/R
 Video	 Smart
 PC	 Media
 Text	 Text
 P+	 Ch +
 Up	 Up
 P-	 Ch -
 Down	 Down
 Right	 Right
 Vol+	 Vol +
 Left	 Left
 Vol-	 Vol -
 Menu	 Menu
 Menu	 Ok
 Mute	 Mute
 Red / M	 Red
 Green	 Green

Originale	Sostituto
 Yellow	 Yellow
 Blue	 Blue
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 -/-	 Guide
 L / ?	 List
 Freeze	 Pause
 M/S	 Options
 PIP	 3D





Originale

Sostituto

	Auto		Back
	F[+]		Format
	i		Info
	F1		Shift + 1
	Clock		AV
	F2		Shift + 2
	F3		Shift + 3
	F4		Shift + 4
	Power		Power

Originale

Sostituto

