







































































Originale		Sostituto		Originale		Sostituto	
	Power		Power		Down		Down
	Stop		Stop		Right		Right
	Pause		Pause		Left		Left
	Rec		Rec		Home		Menu
	<<		<<		Home		Smart
	>>		>>		Back		Back
	Play		Play		CH+ / >I		Ch +
	Red		Red		CH+ / >I		>>I
	Green		Green		CH- / I<		Ch -
	Yellow		Yellow		CH- / I<		I<<
	Blue		Blue		Vol-		Vol -
	Find		Guide		Vol+		Vol +
	Adjust		D. Menu		Mute		Mute
	Source		AV		1		1
	Options		Options		2		2
	OK		Ok		3		3
	Up		Up		4		4



