
















































Originale	Sostituto
 Power	 Power
 TTX / Mix	 Text
 TV / DTV	 Shift + TV/R
 Guide	 Guide
 CH. List	 List
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 APP	 Media
 Pre-CH / Back	 Pre Ch

Originale	Sostituto
 Pre-CH / Back	 Back
 Mute	 Mute
 Vol +	 Vol +
 Vol -	 Vol -
 P +	 Ch +
 P -	 Ch -
 Source	 AV
 Menu	 Menu
 D.Menu	 D. Menu
 Info	 Info
 Exit	 Exit
 Up	 Up
 Left	 Left
 Enter / OK	 Ok
 Right	 Right
 Down	 Down
 Red	 Red





Originale	Sostituto	Originale	Sostituto
 Green	 Green		
 Yellow	 Yellow		
 Blue	 Blue		
 Subtitle	 Subt		
 P.Size	 Format		
 Sleep	 Sleep		
 P.Mode	 Shift + Format		
 S.Mode	 Shift + Dual		
 Dual I-II	 Dual		
 TV / Radio	 TV/R		
 ALT	 Smart		
 Text	 Shift + Text		
 PIP	 Options		
 Still	 Pause		
 PIP Swap	 3D		

