







































































| Originale | | Sostituto | | Originale | | Sostituto | |
|---|---------------|---|--------------------------|---|--------|---|-----------------------------|
|  | Power |  | Power |  | -/-- |  | Shift + Guide / EPG / -/-- |
|  | Mute |  | Mute / Dimmer |  | Recall |  | Back / Return |
|  | Aspect |  | Shift + Picture / Format |  | Red |  | Red / Netflix / Search |
|  | P.Mode |  | Picture / Format |  | Green |  | Green / APP / Repeat |
|  | S.Mode |  | Sound / Title |  | Yellow |  | Yellow / YouTube / Repeat |
|  | Audio / Nicam |  | Audio / Lang I/II |  | Blue |  | Blue / Prime Video / Random |
|  | Sleep |  | Sleep / Timer |  | Source |  | AV / Input / RDS |
|  | 1 |  | 1 |  | Up |  | Up |
|  | 2 |  | 2 |  | Menu |  | Menu / Home |
|  | 3 |  | 3 |  | Left |  | Left |
|  | 4 |  | 4 |  | Enter |  | OK |
|  | 5 |  | 5 |  | Right |  | Right |
|  | 6 |  | 6 |  | Down |  | Down |
|  | 7 |  | 7 |  | Vol + |  | Vol+ |
|  | 8 |  | 8 |  | Exit |  | Exit / Cancel / Clear |
|  | 9 |  | 9 |  | CH + |  | CH+ / Page+ |
|  | 0 |  | 0 |  | Vol - |  | Vol- |



