







































































Originale	Sostituto	Originale	Sostituto
 Power	 Power	 Stop	 Stop
 Source	 AV	 <<	 <<
 1	 1	 Play	 Play
 2	 2	 Pause	 Pause
 3	 3	 >>	 >>
 4	 4	 Mute	 Mute
 5	 5	 Vol+	 Vol +
 6	 6	 Vol-	 Vol -
 7	 7	 P-	 Ch -
 8	 8	 P+	 Ch +
 9	 9	 Menu	 Menu
 0	 0	 Exit	 Exit
 -/--	 Guide	 Up	 Up
 PRE-CH	 Pre Ch	 Down	 Down
 TV	 TV/R	 Right	 Right
 CH.MGR	 Smart	 Left	 Left
 Wiselink	 Media	 Enter	 Ok







































Originale	Sostituto
[= ?]/Info	Info
[= +]/PIP	3D
TTX/MIX	Text
Red	Red
Green	Green
Yellow	Yellow
Blue	Blue
I-II/Dual	Dual
(O)/SRS	Back
Source (Green)	Shift + AV
PC	List
[▼]/STTL	Subt
[<>]/Size	Format
[= ♦]/P.Mode	Shift + Format
[=]/S.Mode	Options
Sleep	Sleep
Power Cable	Shift + Power

Originale	Sostituto
1 Cable	Shift + 1
2 Cable	Shift + 2
3 Cable	Shift + 3
4 Cable	Shift + 4
5 Cable	Shift + 5
6 Cable	Shift + 6
7 Cable	Shift + 7
8 Cable	Shift + 8
9 Cable	Shift + 9
0 Cable	Shift + 0
P+ Cable	Shift + Ch +
P- Cable	Shift + Ch -





Originale	Sostituto
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 PRE-CH	 Pre Ch
 TV	 TV/R
 Sleep	 Sleep
 P+	 Ch +
 P-	 Ch -
 <<	 <<

Originale	Sostituto
 Stop	 Stop
 Play	 Play
 Pause	 Pause
 >>	 >>
 Menu	 Menu
 Exit	 Exit
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 Enter	 Ok
 [≡?]/Info	 Info
 [<>]/Size	 Format
 Source	 AV





Originale	Sostituto	Originale	Sostituto
Power	Power	P+	Ch +
1	1	P-	Ch -
2	2	Up	Up
3	3	Enter	Ok
4	4	Down	Down
5	5	Right	Right
6	6	Left	Left
7	7	Menu	Menu
8	8	Exit	Exit
9	9	[≡?]/Info	Info
0	0		
TV	TV/R		
<<	<<		
Stop	Stop		
Play	Play		
Pause	Pause		
>>	>>		

Originale	Sostituto	Originale	Sostituto
Power	Power	P+	Ch +
1	1	P-	Ch -
2	2	Up	Up
3	3	Enter	Ok
4	4	Down	Down
5	5	Right	Right
6	6	Left	Left
7	7	Menu	Menu
8	8	Exit	Exit
9	9	[≡?]/Info	Info
0	0		
TV	TV/R		
<<	<<		
Stop	Stop		
Play	Play		
Pause	Pause		
>>	>>		

