


























































Originale	Sostituto	Originale	Sostituto
	Power		Power
	Mute		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	TV Portal		Smart
	Menu		Menu
	Play		Play
	Pause		Pause
	Stop		Stop

Originale	Sostituto	Originale	Sostituto
	Rec		Rec
	<<		<<
	>>		>>
	<< / ⏸		<<
	>> / ⏸		>>
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	Media		Media
	Guide		Guide
	Up		Up
	Left		Left
	OK		Ok
	Right		Right
	Down		Down
	Exit		Exit





Originale	Sostituto
 Back	 Back
 Vol +	 Vol +
 Vol -	 Vol -
 List	 List
 i	 Info
 P+ / Page +	 Ch +
 P- / Page -	 Ch -
 OPT+	 Options
 Sound	 Dual
 SUB	 Subt
 TV / Radio	 TV/R
 Text	 Text
 + Book	 Shift + Pre Ch
 Book	 Pre Ch
 I>	 Shift + Right
 Source	 AV
 Sleep	 Sleep

Originale	Sostituto
 V-Format	 Format
 Wide	 3D

