





| Originale | Sostituto |
|-------------|------------------|
| Power | Power |
| Power Tv | + Shift + Power |
| Vol+ Tv | Vol+ |
| AV Input Tv | AV / Input / RDS |
| Vol- Tv | Vol- |
| 1 | 1 |
| 2 | 2 |
| 3 | 3 |
| Open/Close | Eject / Surround |
| 4 | 4 |
| 5 | 5 |
| 6 | 6 |
| PIP | Picture / Format |
| 7 | 7 |
| 8 | 8 |
| 9 | 9 |
| Miracast | Display / Media |

| Originale | Sostituto |
|----------------|----------------------------------|
| Cancel | + Shift + Exit / Cancel / Clear |
| 0 | 0 |
| Audio | Audio / Lang I/II |
| Internet | Text / Goto |
| << Slow Search | << / Tune- |
| Play | Play / Slow |
| Slow Search >> | >> / Tune+ |
| I<< Skip | I<< / Preset- |
| Pause | Pause / Step / Freeze |
| Skip >>I | >>I / Preset+ |
| Status | Info / Angle |
| Stop | Stop / Hold |
| Exit | Exit / Cancel / Clear |
| Pop-Up Menu | Smart / List |
| Top Menu | D.Menu / Top |
| Up | Up |
| Home | Menu / Home |





| Originale | Sostituto |
|---|--|
|  Left |  Left |
|  OK |  OK |
|  Right / II> |  Right |
|  Option |  Setup / OPT / |
|  Down |  Down |
|  Return |  Back / Return |
|  Red |  Red / Netflix / Search |
|  Green |  Green / APP / Repeat |
|  Yellow |  Yellow / YouTube / Repeat |
|  Blue |  Blue / Prime Video / Random |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

| Originale | Sostituto |
|-----------|-----------|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

