



Originale		Sostituto		Originale		Sostituto	
	Power		Power		esc		Exit
	Sky		Smart		help		Shift + Info
	TV		TV/R		Red		Red
	guida tv		Guide		Green		Green
	primafila		Pre Ch		Yellow		Yellow
	menu		Menu		Blue		Blue
	interattivi		Media		1		1
	i		Info		2		2
	Up		Up		3		3
	Left		Left		4		4
	OK		Ok		5		5
	Right		Right		6		6
	Down		Down		7		7
	P+		Ch +		8		8
	P-		Ch -		9		9
	<P> / txt		Back		0		0
	<P> / txt		Text				

