











































































































































| Originale | | Sostituto | | Originale | | Sostituto | |
|---|------------------------|---|---------------|---|-----------------|---|-------|
|  | RCVR On |  | Power |  | RCVR Right |  | Right |
|  | RCVR Standby |  | Shift + Power |  | RCVR Down |  | Down |
|  | RCVR Sleep |  | Sleep |  | RCVR Level |  | Media |
|  | RCVR Return |  | Back |  | RCVR Level Up |  | Smart |
|  | RCVR Setup |  | Options |  | RCVR I<< |  | I<< |
|  | RCVR |  | Ch + |  | RCVR Play |  | Play |
|  | RCVR CH-/Disc |  | Ch - |  | RCVR >>I |  | >>I |
|  | RCVR Vol+ |  | Vol + |  | RCVR << |  | << |
|  | RCVR Vol- |  | Vol - |  | RCVR Stop |  | Stop |
|  | RCVR CH Sel / Top Menu |  | Shift + Menu |  | RCVR >> |  | >> |
|  | RCVR CH Sel / Top Menu |  | D. Menu |  | RCVR Rec / |  | Rec |
|  | RCVR Test / Menu |  | Menu |  | RCVR Play Rev. |  | Pause |
|  | RCVR Audio Sel |  | Dual |  | Open / Close |  | Eject |
|  | RCVR Muting |  | Mute |  | RCVR Input Sel. |  | 1 |
|  | RCVR Up |  | Up |  | RCVR Input Sel. |  | 2 |
|  | RCVR Left |  | Left |  | RCVR Input Sel. |  | 3 |
|  | RCVR Enter |  | Ok |  | RCVR Input Sel. |  | 4 |



























































| Originale | | Sostituto | | Originale | | Sostituto | |
|---|------------------------|---|---------------|---|-------------------|---|-------|
|  | DVD On |  | Power |  | DVD Play |  | Play |
|  | DVD Standby |  | Shift + Power |  | DVD >>I |  | >>I |
|  | DVD Sleep |  | Sleep |  | DVD << |  | << |
|  | DVD Return |  | Back |  | DVD Stop |  | Stop |
|  | DVD Setup |  | Options |  | DVD >> |  | >> |
|  | DVD Disc+ |  | Ch + |  | DVD Random |  | Rec |
|  | DVD Disc- |  | Ch - |  | DVD Pause |  | Pause |
|  | DVD Vol+ |  | Vol + |  | DVD Eject |  | Exit |
|  | DVD Vol- |  | Vol - |  | DVD Input Sel. |  | 1 |
|  | DVD CH Sel / Top Menu |  | Shift + Menu |  | DVD Input Sel. CD |  | 2 |
|  | DVD CH Sel / Top Menu |  | D. Menu |  | DVD Input Sel. V1 |  | 3 |
|  | DVD Test / |  | Menu |  | DVD Input Sel. V2 |  | 4 |
|  | DVD Audio Sel / TV/VCR |  | TV/R |  | DVD Input Sel. V3 |  | 5 |
|  | Muting |  | Mute |  | DVD Input Sel. |  | 6 |
|  | DVD Angle / |  | Format |  | DVD Input Sel. V3 |  | 7 |
|  | DVD Subtitle / Level+ |  | Subt |  | DVD Input Sel. V4 |  | 8 |
|  | DVD I<< |  | I<< |  | DVD Input Sel. V5 |  | 9 |









































































| Originale | | Sostituto | | Originale | | Sostituto | |
|---|----------|---|---------------|---|-----|---|-------|
|  | On |  | Power |  | 2 |  | 2 |
|  | Standby |  | Shift + Power |  | 3 |  | 3 |
|  | Disc+ |  | Ch + |  | 4 |  | 4 |
|  | Vol+ |  | Vol + |  | 5 |  | 5 |
|  | Vol- |  | Vol - |  | 6 |  | 6 |
|  | Muting |  | Mute |  | 7 |  | 7 |
|  | Subtitle |  | Subt |  | 8 |  | 8 |
|  | I<< |  | I<< |  | 9 |  | 9 |
|  | Play |  | Play |  | 0 |  | 0 |
|  | >>I |  | >>I |  | +10 |  | Guide |
|  | << |  | << | | | | |
|  | Stop |  | Stop | | | | |
|  | >> |  | >> | | | | |
|  | Pause |  | Pause | | | | |
|  | Random |  | Rec | | | | |
|  | Eject |  | Eject | | | | |
|  | 1 |  | 1 | | | | |





| Originale | | Sostituto | | Originale | | Sostituto | |
|---|-------------|---|---------------|---|-------------------|---|--------|
|  | NET A |  | Smart |  | Play |  | Play |
|  | On |  | Power |  | >> |  | >> |
|  | Standby |  | Shift + Power |  | << |  | << |
|  | Sleep |  | Sleep |  | Stop |  | Stop |
|  | Display |  | Info |  | >> |  | >> |
|  | Setup |  | Options |  | Rec / Random |  | Rec |
|  | CH+ / Disc+ |  | Ch + |  | Pause / Play Rev. |  | Pause |
|  | CH- / Disc- |  | Ch - |  | Eject / Repeat |  | Exit |
|  | Vol+ |  | Vol + |  | Eject / Repeat |  | Text |
|  | Vol- |  | Vol - |  | Album |  | Red |
|  | Up |  | Up |  | Artist |  | Green |
|  | Left |  | Left |  | Genere |  | Yellow |
|  | Enter |  | Ok |  | Playlist |  | Blue |
|  | Right |  | Right |  | 1 / Symbols |  | 1 |
|  | Down |  | Down |  | 2 / ABC |  | 2 |
|  | Muting |  | Mute |  | 3 / DEF |  | 3 |
|  | I<< |  | I<< |  | 4 / GHI |  | 4 |



