



Originale	Sostituto	Originale	Sostituto
 Standby / On	 Power	 TRK. -	 Ch -
 1	 1	 Open / Close	 Eject
 2	 2	 Timer Rec	 Shift + AV
 3	 3	 I<<	 I<<
 4	 4	 F.Adv / Skip	 3D
 5	 5	 Marker	 Pre Ch
 6	 6	 >>I	 >>I
 7	 7	 <<	 <<
 8	 8	 Stop	 Stop
 9	 9	 Play/Pause	 Play
 0	 0	 >>	 >>
 IPC	 Red	 Title List / Disc Menu	 D. Menu
 Audio	 Dual	 Menu	 Menu
 Select DVD	 Smart	 Anykey	 Green
 Select VCR	 Media	 Play List / Title Menu	 List
 Input Select	 AV	 Up	 Up
 TRK. +	 Ch +	 Left	 Left

Originale	Sostituto	Originale	Sostituto
 Standby / On	 Power	 TRK. -	 Ch -
 1	 1	 Open / Close	 Eject
 2	 2	 Timer Rec	 Shift + AV
 3	 3	 I<<	 I<<
 4	 4	 F.Adv / Skip	 3D
 5	 5	 Marker	 Pre Ch
 6	 6	 >>I	 >>I
 7	 7	 <<	 <<
 8	 8	 Stop	 Stop
 9	 9	 Play/Pause	 Play
 0	 0	 >>	 >>
 IPC	 Red	 Title List / Disc Menu	 D. Menu
 Audio	 Dual	 Menu	 Menu
 Select DVD	 Smart	 Anykey	 Green
 Select VCR	 Media	 Play List / Title Menu	 List
 Input Select	 AV	 Up	 Up
 TRK. +	 Ch +	 Left	 Left







