




















































Originale	Sostituto
 Power Receiver	 Power
Display/▼	 Ch -
Menu/▲	 Ch +
Return / Repeat	 Text
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 +10	 Guide
 Option	 Options


















Originale	Sostituto
 Volume +	 Vol +
 Volume -	 Vol -
Tuning +	 >>
Tuning -	 <<
Up	 Up
Left	 Left
 Enter	 Ok
Right	 Right
Down	 Down
 Return / Repeat	 Back
 Info	 Info
 Phono	 Shift + 1
 Tape	 Shift + 2
 CD	 Shift + 3
 Line 1	 Shift + 4
 Line 2	 Shift + 5
 Line 3	 Shift + 6







Originale	Sostituto	Originale	Sostituto
Power Receiver		Power	
Sleep		Sleep	
Info		Info	
FM		Smart	
AM		Media	
Tuning+		Ch +	
Tuning-		Ch -	
Preset+		Blue	
Preset-		Yellow	
Vol+		Vol +	
Vol-		Vol -	
Option		Options	
Mute		Mute	
Menu/▲		Menu	
Display/▼	 +  Shift + Info		
Return/Repeat		Back	
Up		Up	

Originale	Sostituto	Originale	Sostituto
Down		Down	
Right		Right	
Left		Left	
Enter		Ok	
1		1	
2		2	
3		3	
4		4	
5		5	
6		6	
7		7	
8		8	
9		9	
0		0	
+10		Guide	
Enter2		Pre Ch	
Power Source		Text	



