



Originale		Sostituto		Originale		Sostituto	
	Power		Power		CH List		List
	Source		AV		P+		Ch +
1	1		1		P-		Ch -
2	2		2		Menu		Menu
3	3		3		Smart Hub		Smart
4	4		4		Guide		Guide
5	5		5		Tools		Options
6	6		6		Info		Info
7	7		7		Return		Back
8	8		8		Exit		Exit
9	9		9		Up		Up
0	0		0		Down		Down
	TTX/MIX		Text		Right		Right
	PRE-CH		Pre Ch		Left		Left
	Vol+		Vol +		Enter		Ok
	Vol-		Vol -		Red		Red
	Mute		Mute		Green		Green





Originale		Sostituto		Originale		Sostituto	
	Yellow		Yellow				
	Blue		Blue				
	Search		TV/R				
	Status		Media				
	AD/Subt.		Subt				
	E-Manual		D. Menu				
	Recommend		Format				
	3D		3D				
	<<		<<				
	I<<		I<<				
	Pause		Pause				
	>>		>>				
	>>I		>>I				
	Rec		Rec				
	Play		Play				
	Stop		Stop				

