



Originale	Sostituto
Power	Power
Source	AV
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
TTX/MIX	Text
PRE-CH	Back
Vol+	Vol +
Vol-	Vol -
Mute	Mute

Originale	Sostituto
CH List	List
P+ / Page+	Ch +
P- / Page-	Ch -
Smart Hub	Smart
Menu	Menu
Guide	Guide
Tools	Options
Info	Info
Up	Up
Left	Left
Enter	Ok
Right	Right
Down	Down
Return	Shift + Back
Exit	Exit
Red	Red
Green	Green





Originale	Sostituto	Originale	Sostituto
Yellow	Yellow		
Blue	Blue		
Rec	Rec		
3D	3D		
AD/Subt.	Subt		
Stop	Stop		
<</ <<	<<		
<</ <<	I<<		
Play	Play		
Pause	Pause		
>>/>>	>>		
>>/>>	>>		

