





































Originale	Sostituto
 Power	 Power
 [i+]	 Info
 DTT/TV	 TV/R
 AV1	 Shift + 1
 AV2	 Shift + 2
 AV3	 Shift + 3
 AV4	 Shift + 4
 AV5	 Shift + 5
 RGB1	 Shift + 7
 RGB2	 Shift + 8
 Menu	 Menu
 Back	 Back
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok

Originale	Sostituto
 ♪ / S.Mode	 Shift + Dual
 ⏻ / P.Mode	 Shift + Format
 Vol+	 Vol +
 Vol-	 Vol -
 I/II	 Dual
 Mute	 Mute
 P+	 Ch +
 P-	 Ch -
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9

































Originale	Sostituto	Originale	Sostituto
 0	 0		
 2-4-12 / [▶◀]	 ECO 3D		
 [≡]	 SETTINGS OPT Options		
 Red	 A Red		
 Green	 B Green		
 Yellow	 C Yellow		
 Blue	 D Blue		
 [≡i]	 DISC NAV LIST List		
 [≡X]	 HOME SMART Smart		
 [...] / Slide Show	 AD SUBT Subt		
 [≡?]/Rotate	 FAV PRE-CH Pre Ch		
 [≡]	 REPEAT TEXT Text		
 SWIVEL	 PROG SLEEP Sleep		
 [<>]	 PICTURE FORMAT Format		
 PHOTO	 APP MEDIA Media		

Originale	Sostituto	Originale	Sostituto













































Originale		Sostituto		Originale	Sostituto
	Power		Power		
	OK		Ok		
	Up		Up		
	Down		Down		
	Right		Right		
	Left		Left		
	Menu		Menu		
	Play		Play		
	Stop		Stop		
	Pause		Pause		
	<<		<<		
	>>		>>		
	P+		Ch +		
	P-		Ch -		





Originale		Sostituto		Originale		Sostituto	
	Power		Power		8		8
	OK		Ok		9		9
	Up		Up		0		0
	Down		Down				
	Right		Right				
	Left		Left				
	P+		Ch +				
	P-		Ch -				
	Vol+		Vol +				
	Vol-		Vol -				
	1		1				
	2		2				
	3		3				
	4		4				
	5		5				
	6		6				
	7		7				

