





















































































































Originale	Sostituto	Originale	Sostituto
 Power	 Power	 Prog-	 Ch -
 Open / Close	 Eject	 Input Select	 AV
 HDD	 Media	 TV / DVD	 TV/R
 DVD	 Smart	 Top Menu	 Shift + Menu
 1	 1	 Menu	 Menu
 2	 2	 System Menu	 D. Menu
 3	 3	 Chapter Mark	 Guide
 4	 4	 Mark Erase	 Pre Ch
 5	 5	 Title List	 List
 6	 6	 Timer	 Sleep
 7	 7	 Display	 Info
 8	 8	 Timer List	 Mute
 9	 9	 Up	 Up
 0	 0	 Left	 Left
 Audio	 Dual	 Enter	 Ok
 Subtitle	 Subt	 Right	 Right
 Prog+	 Ch +	 Down	 Down

Originale	Sostituto	Originale	Sostituto
 Power	 MUTE	 SHIFT	
 TV	 DVD	 SAT	 AUX
 PLAY MODE	 REC MODE	 ▶	 ⏸
 ⏮	 ⏭	 ■	 ●
 DISC NAV	 SOUND	 AD	 SETTINGS
 LIST	 DUAL	 SUBT	 OPT
 PROG	 SEARCH	 PICTURE	 ECO
 SLEEP	 TV/R	 FORMAT	 3D
 E-MANUAL	 REPEAT	 ZOOM	 TIMER
 D.MENU	 TEXT	 ▲	 AV
 TOP MENU	 MENU	 INFO	
 CLEAR	 EXIT	 RETURN	 BACK
 +	 HOME	 SMART	 +
 -	 APP	 MEDIA	 -
 1	 2	 3	
 4	 5	 6	
 7	 8	 9	
 GUIDE	 0	 PRE-CH	
 A	 B	 C	 D
			
www.mandis.tv			





Originale	Sostituto
 Return	 Back
 Options	 Options
 I<<	 I<<
 >>I	 >>I
 ⏏	 Vol -
 ⏪ ⏩	 Vol +
 << / <II / <I	 <<
 Play	 Play
 >> / I> / II>	 >>
 Time / Text	 Text
 Pause	 Pause
 Stop	 Stop
 Rec	 Rec
 Rec Stop	 Shift + Stop
 Rec Mode	 Shift + Rec
 Synchro Rec	 Red
 TV Power	 Shift + Power

Originale	Sostituto
 TV Input	 Shift + AV
 TV Prog+	 Shift + Ch +
 TV Vol+	 Shift + Vol +
 TV Vol-	 Shift + Vol -
 TV Prog-	 Shift + Ch -

