



Originale	Sostituto
Power	Power
Mute	Mute
Red/Title	Red
Green/Goto	Green
Yellow/Repeat	Yellow
Blue/A-B	Blue
<</Index	<<
>>/Hold	>>
I<</Size	I<<
>>I/Subpage	>>I
Play	Play
Pause	Pause
Stop	Stop
Eject	Eject
Subtitle	Subt
D.Set/Tv/TXT	Text
D.Menu/Cancel	D. Menu

Originale	Sostituto
D.Sub/Reveal	Media
D.Lan/Nicam/A2	Dual
Tv/Radio	TV/R
FAV	Pre Ch
Nothing	Shift + Back
Sleep	Sleep
Disp	Info
Input	AV
Menu	Menu
Exit	Exit
Up	Up
Down	Down
Right	Right
Left	Left
OK	Ok
Vol+	Vol +
Vol-	Vol -



