







































































Originale		Sostituto		Originale		Sostituto	
	Power		Power		Vol-		Vol -
	[i+]		Info		Mute		Mute
	[1]2 Dual Screen		Smart		P+		Ch +
	Red / Demo		Red		P-		Ch -
	Green		Green		1		1
	Yellow		Yellow		2		2
	Blue		Blue		3		3
	Option		Options		4		4
	Guide		Guide		5		5
	Up		Up		6		6
	Left		Left		7		7
	OK		Ok		8		8
	Right		Right		9		9
	Down		Down		0		0
	Menu / Browse		Menu		AV		AV
	Text		Text		P<P		Back
	Vol+		Vol +		<<		<<





Originale		Sostituto		Originale		Sostituto	
	Stop / MHEG		Stop				
	Play		Play				
	>>		>>				
	Rec		Rec				
	FAV		Pre Ch				

