




Originale	Sostituto	Originale	Sostituto
 Power	 Power	 A-B	 TV/R
 Sleep	 Sleep	 Program	 Shift + Sleep
 Dimmer	 Media	 Volume+	 Vol +
 Open/Close	 Eject	 Volume-	 Vol -
 1	 1	 Mute	 Mute
 2	 2	 Title	 List
 3	 3	 Menu/PBC	 Menu
 4	 4	 Return	 Back
 5	 5	 Setup	 Options
 6	 6	 Up	 Up
 7	 7	 Down	 Down
 8	 8	 Right	 Right
 9	 9	 Left	 Left
 0	 0	 Enter	 Ok
 >10	 Guide	 Stop	 Stop
 Repeat	 Text	 Play	 Play
 Goto	 3D	 Pause	 Pause

Originale	Sostituto	Originale	Sostituto
 A-B	 TV/R	 TV	 DVD
 Program	 Shift + Sleep	 SAT	 AUX
 Volume+	 Vol +	 TV	 DVD
 Volume-	 Vol -	 II	 ■
 Mute	 Mute	 ◀	 ▶
 Title	 List	 ◀◀	 ▶▶
 Menu/PBC	 Menu	 LIST	 SOUND
 Return	 Back	 DUAL	 SUBT
 Setup	 Options	 SEARCH	 PICTURE
 Up	 Up	 SLEEP	 FORMAT
 Down	 Down	 TV/R	 3D
 Right	 Right	 E-MANUAL	 TIMER
 Left	 Left	 REPEAT	 ZOOM
 Enter	 Ok	 TEXT	 AV
 Stop	 Stop	 D.MENU	 TOP MENU
 Play	 Play	 MENU	 DISPLAY
 Pause	 Pause	 OK	 INFO
		 CLEAR	 RETURN
		 EXIT	 BACK
		 + VOL	 HOME
		 - VOL	 SMART
		 1	 APP
		 2	 MEDIA
		 3	 + CH
		 4	 1
		 5	 2
		 6	 3
		 7	 4
		 8	 5
		 9	 6
		 0	 7
		 GUIDE	 8
		 A	 9
		 B	 FAV
		 C	 PRE-CH
		 D	





Originale		Sostituto	
	<<		<<
	>>		>>
	I<<		I<<
	>>I		>>I
	Language		Dual
	Subtitle		Subt
	PAL/NTSC		Format
	Audio		Shift + Dual
	Zoom		Shift + Eject
	Angle		Smart
	Slow		AV
	Display		Info
	Nothing		Pre Ch

Originale	Sostituto

