







































Originale	Sostituto
 Power	 Power
 Open/Close	 Eject
 Function	 AV
 Subtitle	 Subt
 Home	 Smart
 Sleep	 Sleep
 Disc Menu	 D. Menu
 Info Menu	 Info
 Info Menu	 Menu
 Enter	 Ok
 Up	 Up
 Preset+	 Ch +
 Down	 Down
 Preset-	 Ch -
 Right/Tuning+	 Right
 Left/Tuning-	 Left
 Back	 Back

Originale	Sostituto
 Title/PopUp	 Media
 Play	 Play
 Pause/Step	 Pause
 Stop	 Stop
 Scan >>	 >>
 << Scan	 <<
 Skip >>	 >>
 << Skip	 <<
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 Sound Effect	 Dual
 Optical Tv Sound	 TV/R
 Speaker Level	 Options
 Red/RDS	 Red
 Green/PTY	 Green
 Yellow/PTY Search	 Yellow



