







Originale	Sostituto
 Power	 Power
 Power Tv	 Shift + Power
 Optical	 Options
 Coaxial	 3D
 Analog	 Subt
 Prog- Tv	 Ch -
 Prog+ Tv	 Ch +
 Vol+ Tv	 Shift + Vol +
 Vol- Tv	 Shift + Vol -
 Mute Tv	 Shift + Mute
 Source Tv	 AV
 Mute	 Mute
 Surround	 Dual
 Vol+	 Vol +
 Vol-	 Vol -
 Treble+	 Up
 Treble-	 Down

Originale	Sostituto
 Bass-	 Left
 Bass+	 Right

