



| Originale | Sostituto |
|------------|--------------------|
| Power | Power |
| Mute | Mute / Dimmer |
| 1 | 1 |
| 2 | 2 |
| 3 | 3 |
| 4 | 4 |
| 5 | 5 |
| 6 | 6 |
| 7 | 7 |
| 8 | 8 |
| 9 | 9 |
| TV / Radio | TV/Radio / |
| 0 | 0 |
| ←PR | Back / Return |
| EPG | Guide / EPG / -/-- |
| Up / PR+ | CH+ / Page+ |
| Up / PR+ | Up |

| Originale | Sostituto |
|--------------|------------------------|
| Menu | Menu / Home |
| Left / Vol- | Left |
| Left / Vol- | Vol- |
| OK / List | OK |
| OK / List | Smart / List |
| Right / Vol+ | Vol+ |
| Right / Vol+ | Right |
| FAV | Fav / Marker / PC |
| Down / PR- | CH- / Page- |
| Down / PR- | Down |
| Exit | Exit / Cancel / Clear |
| Red / Find | Red / Netflix / Search |
| ↑ | >> / Preset+ |
| ↑ | >> / Tune+ |
| Green / Zoom | Zoom / Size |
| Green / Zoom | Green / APP / Repeat |
| ↓ | << / Tune- |





| Originale | | Sostituto | |
|-----------|--------------|-----------|-----------------------------|
| | ↓ | | I<< / Preset- |
| | Blue / LR | | Blue / Prime Video / Random |
| | Blue / LR | | Audio / Lang I/II |
| | Yellow / TXT | | Text / Goto |
| | Yellow / TXT | | Yellow / YouTube / Repeat |
| | Pause | | Pause / Step / Freeze |
| | SAT | | Shift + 0 |
| | SAT | | Display / Media |
| | TV / AV | | AV / Input / RDS |
| | Sleep | | Sleep / Timer |
| | [::] | | Picture / Format |
| | Info | | Info / Angle |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Originale | | Sostituto | |
|-----------|--|-----------|--|
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

