



Originale	Sostituto
 Power	 Power
 Eject	 Eject
 DVD	 Shift + 1
 TUNER	 Shift + 2
 PORT	 Shift + 3
 AUX	 Shift + 4
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Audio	 Dual

Originale	Sostituto
 Subtitle	 Subt
 I<<	 I<<
 Step	 Shift + Pause
 Pause	 Pause
 >>I	 >>I
 <<	 <<
 Stop	 Stop
 Play	 Play
 >>	 >>
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 Remain	 Smart
 Tuning+ / CH+	 Ch +
 Tuning- / CH-	 Ch -
 Menu	 Menu
 Return	 Back





