


























































Originale	Sostituto
 Standby	 Power
 Source	 AV
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 -/--	 GUIDE
 Display	 INFO
 Picture	 SHIFT +  Shift + Format
 Sleep	 SLEEP
 Mode	 SMART

Originale	Sostituto
 Return	 BACK
 Up	 Up
 Left	 Left
 Menu	 TOP MENU
 Menu	 OK
 Right	 Right
 Down	 Down
 Mute	 MUTE
 Zoom	 ZOOM
 Nicam/A2	 SOUND DUAL
 Sound	 SHIFT +  Shift + Dual
 Text	 REPEAT TEXT
 Cancel	 CLEAR EXIT
 Red	 A
 Green	 B
 Yellow	 C
 Cyan	 D




Originale
Sostituto

	Mix		Shift + Text
	Size		Format
	Hold		Stop
	Reveal		Media
	Index		Options
	Subpage		Subt
	Up		Ch +
	Down		Ch -
	Left		Vol -
	Right		Vol +

Originale
Sostituto

