







































































Originale		Sostituto		Originale		Sostituto	
	Power		Power		Yellow		Yellow
	Mute		Mute		Blue		Blue
	1		1		i		Info
	2		2		Text		Text
	3		3		Up / P+		Up
	4		4		Up / P+		Ch +
	5		5		Down / P-		Down
	6		6		Down / P-		Ch -
	7		7		Right / Vol+		Vol +
	8		8		Right / Vol+		Right
	9		9		Left / Vol-		Vol -
	0 / AV		0		Left / Vol-		Left
	0 / AV		AV		Menu / OK		Menu
	Red / Zoom		Red		Menu / OK		Ok
	Red / Zoom		Eject		[[]]		Stop
	Green / Audio		Green		F.T/L		Smart
	Green / Audio		Dual		[?]		Media




















Originale		Sostituto		Originale		Sostituto	
	Power		Power				
	Menu		Menu				
	OK		Ok				
	Up		Up				
	Down		Down				
	Right		Right				
	Left		Left				
	<<		<<				
	Play		Play				
	>>		>>				
	Stop		Stop				
	Rec		Rec				
	↑		Ch +				
	↓		Ch -				





	Originale	Sostituto	Originale	Sostituto
	Power			
	<<			
	Play			
	>>			
	Rec			
	Stop			
	Up			
	Down	