









































































Originale	Sostituto	Originale	Sostituto
 Power	 Power	 Vol-	 Vol -
 TV/R	 TV/R	 Back	 Back
 APP	 Media	 Exit	 Exit
 Mute	 Mute	 CH+	 Ch +
 1	 1	 CH-	 Ch -
 2	 2	 EPG	 Guide
 3	 3	 Menu	 Menu
 4	 4	 Up	 Up
 5	 5	 Left	 Left
 6	 6	 OK	 Ok
 7	 7	 Right	 Right
 8	 8	 Down	 Down
 9	 9	 Rec	 Rec
 0	 0	 PVR	 Options
 Info	 Info	 Play / Pause	 Play
 PiP	 Smart	 Play / Pause	 Pause
 Vol+	 Vol +	 Stop	 Stop





Originale	Sostituto
 <<	 <<
 >>	 >>
 Mark	 3D
 List	 List
 Audio	 Dual
 FAV	 Pre Ch
 Sleep	 Sleep
 Pup	 Shift + Ch +
 Sub	 Subt
 Fav+	 >>
 Text	 Text
 Pdn	 Shift + Ch -
 Zoom	 Eject
 Fav-	 I<<
 Red	 Red
 Green	 Green
 Yellow	 Yellow

Originale	Sostituto
 Blue	 Blue

