











































Originale	Sostituto
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 [=]	 Text
 FAV	 Pre Ch
 Menu	 Menu
 EPG	 Guide
 i	 Info

Originale	Sostituto
 Back	 Back
 VOD	 Smart
 Vol+	 Vol +
 Vol-	 Vol -
 CH+	 Ch +
 CH-	 Ch -
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 PVR	 Media
 Red	 Red
 Green	 Green
 Yellow/Lang	 Yellow
 Blue	 Blue
 ?	 Options





	Originale	Sostituto	Originale	Sostituto
	<<			<<
	>>			>>
	Play			Play
	Pause			Pause
	Stop			Stop
	Rec			Rec
	TV			3D
	Radio			TV/R
	Messages			Subt
	Search			Shift + TV/R
	.:l			Dual

