



Originale	Sostituto
 Standby/On	 Power
 STB	 Green
 VCR	 Yellow
 DVD	 Blue
 AUX	 Red
 TV	 TV/R
 Vol Mode	 Dual
 Auto Setup	 Media
 Input Mode	 AV
 Sleep	 Sleep
 1/5Beam	 1
 2/ST+3Beam	 2
 3/3Beam	 3
 4/Stereo	 4
 5/My Beam	 5
 6/My Sur.	 6
 Sur. Decode	 Options

Originale	Sostituto
 CH Level	 Smart
 Menu	 Menu
 Return	 Back
 Test	 Pre Ch
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 Enter	 Ok
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute





Originale	Sostituto
 Power Tv	 Power
 STB	 Green
 VCR	 Yellow
 DVD	 Blue
 AUX	 Red
 TV	 TV/R
 Input 1 Tv	 Text
 Input 2 Tv	 Eject
 Vol. Mode	 Dual
 Auto Setup	 Media
 Input Mode	 Format
 Sleep	 Sleep
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5

Originale	Sostituto
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 +10	 Guide
 Sur.Decode	 Options
 CH Level	 Smart
 Menu	 Menu
 Return	 Back
 Test	 Pre Ch
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 Enter	 Ok
 CH+	 Ch +





Originale		Sostituto		Originale		Sostituto	
	CH-		Ch -				
	Tv Input		AV				
	Tv Vol+		Vol +				
	Tv Vol-		Vol -				
	Tv Mute		Mute				
	<<		<<				
	Stop		Stop				
	>>		>>				
	l<<		l<<				
	Pause		Pause				
	>>l		>>l				
	Play		Play				















Originale	Sostituto	Originale	Sostituto
 Power	 Power		
 Vol+	 Vol +		
 Vol-	 Vol -		
 Mute	 Mute		
 STB	 Green		
 VCR	 Yellow		
 DVD	 Blue		
 AUX	 Red		
 TV	 TV/R		
 <<<	 <<<		
 Stop	 Stop		
 >>>	 >>>		
 <<<	 <<<		
 Pause	 Pause		
 >>	 >>		
 Play	 Play		

Originale	Sostituto





Originale		Sostituto		Originale		Sostituto	
	Power AV		Power				
	Vol+		Vol +				
	Vol-		Vol -				
	Mute		Mute				
	STB		Green				
	AUX		Red				
	VCR		Yellow				
	DVD		Blue				
	TV		TV/R				
	<<		<<				
	Stop		Stop				
	>>		>>				
	Pause		Pause				
	Play		Play				

