





































Originale	Sostituto
 Power	 Power
 FAV	 Pre Ch
 Mute	 Mute
 EPG	 Guide
 Back	 Back
 Next >	 >>I
 Help	 D. Menu
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0

Originale	Sostituto
 Text	 Text
 < Prev	 I<<
 Radio	 TV/R
 TV	 Smart
 Menu	 Menu
 Exit	 Exit
 Up	 Up
 Left	 Left
 OK	 Ok
 Right	 Right
 Down	 Down
 Vol+	 Vol +
 Vol-	 Vol -
 CH+	 Ch +
 CH-	 Ch -
 Red	 Red
 Green	 Green





Originale		Sostituto		Originale		Sostituto	
	Yellow		Yellow				
	Blue		Blue				
	<<		<<				
	>>		>>				
	Play / Pause		Play				
	Play / Pause		Pause				
	Stop		Stop				
	Rec		Rec				
	Info		Info				
	Timer		AV				
	Web		Media				
	Plugin		Options				
	Audio		Dual				
	Subtitle		Subt				
	Sleep		Sleep				

