







































































Originale		Sostituto		Originale		Sostituto	
	Power		Power		OK		Ok
	Mute		Mute		Up		Up
	Movie		1		Down		Down
	Music		2		Right		Right
	Photo		3		Left		Left
	Home		Smart		Stop		Stop
	Disk		Menu		Pause		Pause
	All Media		Media		<<		<<
	Subtitle		Subt		>>		>>
	Audio		Dual		I<<		I<<
	Zoom		Eject		>>I		>>I
	Info		Info		Repeat		Text
	Copy Target		Pre Ch		Tv Out		TV/R
	Vol+		Vol +		Setup		Options
	Vol-		Vol -		A-B		D. Menu
	P+		Ch +		BGM/Go to		Format
	P-		Ch -		Slide Type		Guide

