






| Originale | Sostituto |
|--|---|
|  Power |  Power |
|  Sleep |  Sleep |
|  Muting |  Mute |
|  1 / Disc 1 |  1 |
|  2 / Disc 2 |  2 |
|  3 / Disc 3 |  3 |
|  4 / Disc 4 |  4 |
|  5 / Disc 5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  0 |  0 |
|  ≥10 |  Guide |
|  Disc |  Media |
|  Program |  +  Shift + Sleep |
|  Cancel |  Back |

| Originale | Sostituto |
|---|---|
|  Repeat |  Text |
|  Random |  Options |
|  Tape |  Red |
|  CD |  Green |
|  Tuner |  Yellow |
|  AUX |  Blue |
|  EQ |  Subt |
|  3D AI |  3D |
|  I<<< / << |  << |
|  I<<< / << |  I<< |
|  >> / >>I |  >>I |
|  >> / >>I |  >> |
|  Play Rev / Pause / Down |  Pause |
|  Play Rev / Pause / Down |  Down |
|  Play Rev / Pause / Down |  Left |
|  Stop |  Stop |
|  Stop |  Exit |





| Originale | Sostituto |
|---|---|
|  Play / Up |  Play |
|  Play / Up |  Up |
|  Play / Up |  Right |
|  Volume - |  Vol - |
|  Volume + |  Vol + |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

| Originale | Sostituto |
|-----------|-----------|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

