
























































Originale	Sostituto
 Power	 Power
 Mode/Auto	 Smart
 Options	 Options
 FAV	 Shift + Pre Ch
 Sleep	 Sleep
 Red/Demo	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 Menu	 Menu
 Exit	 Exit
 Source	 AV
 Net TV	 Media
 Back	 Back
 Info	 Info
 Up	 Up
 Down	 Down

Originale	Sostituto
 Right	 Right
 Left	 Left
 OK	 Ok
 <<	 <<
 Play	 Play
 Pause	 Pause
 >>	 >>
 Stop	 Stop
 Rec	 Rec
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 Format	 Format
 CH+	 Ch +
 CH-	 Ch -
 1	 1
 2	 2



