





































Originale	Sostituto
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Last View	 Pre Ch
 Radio/Tv	 TV/R
 Internet	 Smart
 Netflix	 Media
 Rec	 Rec
 Prog/Check	 Sleep

Originale	Sostituto
 Play	 Play
 >>	 >>
 <<	 <<
 Pause	 Pause
 >>	 >>
 <<	 <<
 Stop	 Stop
 Exit	 Exit
 i/Status	 Info
 Return	 Back
 Guide	 Guide
 Function Menu	 Menu
 Video Menu	 D. Menu
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left





Originale		Sostituto		Originale		Sostituto	
	OK		Ok		CH+ Tv		Shift + Ch +
	Option		Options		CH- Tv		Shift + Ch -
	Red		Red		Power Tv		Shift + Power
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				
	Audio		Dual				
	Drive Select		List				
	Text		Text				
	STTL		Subt				
	+60s		3D				
	-10s		Format				
	Page/CH+		Ch +				
	Page/CH-		Ch -				
	Tv Vol+		Vol +				
	Tv Vol-		Vol -				
	AV Input Tv		AV				

