


| Originale | Sostituto | Originale | Sostituto |
|--|--|--|--|
|  Power |  Power |  Picture |  Format |
|  Mute |  Mute |  AV |  AV |
|  1 |  1 |  Menu |  Menu |
|  2 |  2 |  PR+ |  Ch + |
|  3 |  3 |  Up |  Up |
|  4 |  4 |  PR- |  Ch - |
|  5 |  5 |  Down |  Down |
|  6 |  6 |  Right |  Right |
|  7 |  7 |  Vol+ |  Vol + |
|  8 |  8 |  Vol- |  Vol - |
|  9 |  9 |  Left |  Left |
|  0 |  0 |  Up VCR |  Shift + Ch - |
|  Red/Zoom |  Red |  UP [≡] |  Shift + Text |
|  Green/OO |  Green |  Up DVD |  Shift + Up |
|  Yellow |  Yellow |  Down VCR |  Shift + Ch + |
|  Blue |  Blue |  Down DVD |  Shift + Down |
|  Text |  Text |  << VCR |  Shift + << |

| Originale | Sostituto | Originale | Sostituto |
|--|--|--|--|
|  Picture |  Format |  AV |  AV |
|  Menu |  Menu |  PR+ |  Ch + |
|  Up |  Up |  PR- |  Ch - |
|  Down |  Down |  Right |  Right |
|  Vol+ |  Vol + |  Vol- |  Vol - |
|  Left |  Left |  Up VCR |  Shift + Ch - |
|  UP [≡] |  Shift + Text |  Up DVD |  Shift + Up |
|  Down VCR |  Shift + Ch + |  Down DVD |  Shift + Down |
|  << VCR |  Shift + << | | |



