





































| Originale | Sostituto |
|---|--|
|  Power |  Power |
|  TV/VTR |  TV/Radio / |
|  Eject |  Eject / Surround |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  0 |  0 |
|  -/-- |  Guide / EPG / -/-- |
|  Prog+ |  CH+ / Page+ |
|  Prog- |  CH- / Page- |
|  Vol+ |  Vol+ |

| Originale | Sostituto |
|--|---|
|  Vol- |  Vol- |
|  Play |  Play / Slow |
|  Stop |  Stop / Hold |
|  Pause |  Pause / Step / Freeze |
|  Search >> |  >> / Tune+ |
|  Index Search >> |  >> / Preset+ |
|  I<< Index Search |  I<< / Preset- |
|  X2 |  Smart / List |
|  << Search |  << / Tune- |
|  Skip |  Exit / Cancel / Clear |
|  Wheel >/Frame |  Shift + >> / Preset+ |
|  Up |  Up |
|  < Wheel/< |  Shift + I<< / Preset- |
|  Down |  Down |
|  Right |  Right |
|  Left |  Left |
|  Menu |  Menu / Home |





Originale

Sostituto

| | | | |
|--|------------------------|--|-------------------------------|
| | Execute | | Blue / Prime Video / Random |
| | Input Select | | AV / Input / RDS |
| | Audio Monitor | | Audio / Lang I/II |
| | Time Clear | | Shift + Exit / Cancel / Clear |
| | Auto/Manu | | Setup / OPT / |
| | Tracking Normal/Slow ▼ | | Shift + CH- / |
| | Display | | Display / Media |
| | Tracking Normal/Slow ▲ | | Shift + CH+ / |
| | Counter Reset | | Back / Return |
| | Rec | | Rec / Rec Mode |
| | Tape Speed SP/LP | | Zoom / Size |
| | Still Adjust I> Slow+ | | Shift + >> / |
| | Still Adjust I> Slow- | | Shift + << / |
| | Quick Timer | | Sleep / Timer |
| | Timer Check | | Shift + Sleep / Timer |
| | Showview | | Picture / Format |
| | VPS/PDC | | D.Menu / Top |

Originale

Sostituto

| | | | |
|--|--------|--|---------------------------|
| | Once | | Red / Netflix / Search |
| | Daily | | Green / APP / Repeat |
| | Weekly | | Yellow / YouTube / Repeat |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |





| Originale | Sostituto |
|-----------|--------------------|
| Power | Power |
| Display | Display / Media |
| TV/VTR | TV/Radio / |
| 1 | 1 |
| 2 | 2 |
| 3 | 3 |
| 4 | 4 |
| 5 | 5 |
| 6 | 6 |
| 7 | 7 |
| 8 | 8 |
| 9 | 9 |
| 0 | 0 |
| -/-- | Guide / EPG / -/-- |
| Vol+ | Vol+ |
| Vol- | Vol- |
| Prog+ | CH+ / Page+ |

| Originale | Sostituto |
|---------------|-----------------------------|
| Prog- | CH- / Page- |
| Audio Monitor | Audio / Lang I/II |
| Red | Red / Netflix / Search |
| Green | Green / APP / Repeat |
| Yellow | Yellow / YouTube / Repeat |
| Blue | Blue / Prime Video / Random |
| [≡] | Text / Goto |
| [] | Smart / List |

