























































Originale	Sostituto
 Power	 Power
 Input	 AV
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Guide	 Guide
 CH List	 List
 Red	 Red
 Green	 Green
 Yellow	 Yellow

Originale	Sostituto
 Blue	 Blue
 [≡]	 Menu
 Play	 Play
 Pause	 Pause
 Back	 Back
 Exit	 Exit
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 Home	 Smart
 CH+	 Ch +
 CH-	 Ch -





Originale		Sostituto	
	Subtitle		Subt
	Info		Info
	TXT		Text
	Music		3D
	Free		Options
	ART		Dual
	Netflix		Shift + Media
	Prime Video		Format
	YouTube		Shift + Smart
	Rakuten TV		TV/R
	Media		Media
	[++]		D. Menu

Originale	Sostituto

