

































































Originale		Sostituto		Originale		Sostituto	
	Power		Power		Left / Vol-		Left
	Mute		Mute		Left / Vol-		Vol -
	Back		Back		OK		Ok
	EPG		Guide		FAV		Pre Ch
	Lang		Dual		TV/R		TV/R
	Info		Info		List		List
	Repeat		Shift + Text		Goto		Media
	TTX		Text		1		1
	S-T		Subt		2		2
	Menu		Menu		3		3
	Exit		Exit		4		4
	Up / CH+		Up		5		5
	Up / CH+		Ch +		6		6
	Down / CH-		Down		7		7
	Down / CH-		Ch -		8		8
	Right / Vol+		Right		9		9
	Right / Vol+		Vol +		0		0



