



Originale		Sostituto		Originale		Sostituto	
	POWER		Power		P+		Ch +
	1		1		P-		Ch -
	2		2		UP		Up
	3		3		LEFT		Left
	4		4		OK		Ok
	5		5		RIGHT		Right
	6		6		DOWN		Down
	7		7		INFO		Info
	8		8		GUIDE		Guide
	9		9		TV		TV/R
	0		0		RADIO		Shift + TV/R
	MENU		Menu		RED		Red
	EXIT		Exit		GREEN		Green
	V+		Vol +		YELLOW		Yellow
	V-		Vol -		BLUE		Blue
	MUTE		Mute		TXT		Text
	←		Back				

