





































Originale	Sostituto
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 SAT	 Smart
 Zoom	 Eject
 FAV+	 >>I
 FAV-	 I<<
 Up/CH+	 Up









Originale	Sostituto
 Down/CH-	 Down
 Vol+	 Vol +
 Right	 Right
 Left	 Left
 Vol-	 Vol -
 OK	 Ok
 Exit	 Exit
 Audio	 Dual
 Red	 Red
 Menu	 Menu
 PgUp	 Ch +
 PgDn	 Ch -
 FAV	 Pre Ch
 EPG	 Guide
 Tv/Radio	 TV/R
 Green	 Green
 Recall	 Back





Originale

Sostituto



































	Yellow		Yellow
	Pause		Pause
	Blue		Blue
	Info		Info

















Originale

Sostituto





Originale	Sostituto
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 SAT	 Smart
 Zoom	 Eject
 FAV+	 >>I
 FAV-	 I<<
 Up/CH+	 Up

Originale	Sostituto
 Down/CH-	 Down
 Vol+	 Vol +
 Right	 Right
 Left	 Left
 Vol-	 Vol -
 OK	 Ok
 Exit	 Exit
 Audio	 Dual
 Menu	 Menu
 Red	 Red
 PgUp	 Ch +
 PgDn	 Ch -
 FAV	 Pre Ch
 EPG	 Guide
 Tv/Radio	 TV/R
 Green	 Green
 Recall	 Back





Originale		Sostituto		Originale		Sostituto	
	Yellow		Yellow				
	Pause		Pause				
	Blue		Blue				
	Info		Info				





Originale	Sostituto
Power	Power
Mute	Mute
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
SAT	Smart
Zoom	Eject
FAV+	>>I
FAV-	I<<
Up/CH+	Up

Originale	Sostituto
Down/CH-	Down
Right	Right
Vol+	Vol +
Vol-	Vol -
Left	Left
OK	Ok
Exit	Exit
Audio	Dual
Red	Red
Menu	Menu
PgUp	Ch +
PgDn	Ch -
FAV	Pre Ch
EPG	Guide
Tv/Radio	TV/R
Green	Green
Recall	Back





Originale		Sostituto		Originale		Sostituto	
	Pause		Pause				
	Yellow		Yellow				
	Info		Info				
	Blue		Blue				

