

























































































Originale	Sostituto	Originale	Sostituto
 Operate	 Power	 Tv Prog-	 Ch -
 1	 1	 Right	 Right
 2	 2	 Left	 Left
 3	 3		
 4	 4		
 5	 5		
 6	 6		
 7	 7		
 8	 8		
 9	 9		
 0	 0		
 Tv/Video	 TV/R		
 Mute	 Mute		
 "/	 Dual		
 Tv Vol+	 Vol +		
 Tv Vol-	 Vol -		
 Tv Prog+	 Ch +		

Originale	Sostituto
 Tv Prog-	 Ch -
 Right	 Right
 Left	 Left


















Originale	Sostituto
 Operate	 Power
 Store	 Smart
 CH Set	 Media
 Review	 Guide
 Clock	 Back
 C.Memory/Display	 Info
 Mode	 Format
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0

Originale	Sostituto
 C.Reset/Cancel	 Exit
 Start+	 Vol +
 Timer	 AV
 Start-	 Vol -
 Stop+	 Up
 Stop-	 Down
 Date+	 Right
 Date-	 Left
 Tv Prog+/Up	 Ch +
 Tv Prog-/Down	 Ch -
 AudioMonitor	 Dual
 AudioMonitor	 Mute
 Tv/Video	 TV/R
 Play	 Play
 Rec	 Rec









































































Originale	Sostituto
 Stop	 Stop
 Pause	 Pause
 Scene Finder	 3D
 Prog/Check	 Menu
 Prog	 Sleep
 OK	 Ok
 >>I/Push Jog+	 >>I
 I<</Push Jog-	 I<<

Originale	Sostituto





Originale	Sostituto	Originale	Sostituto
 Operate	 Power	 C.Reset/Cancel	 Exit
 Store	 Smart	 Timer	 AV
 CH Set	 Media	 Start+	 Vol +
 Review	 Guide	 Start-	 Vol -
 Clock	 Back	 Stop+	 Up
 C.Memory Display	 Info	 Stop-	 Down
 Mode	 Format	 Date+	 Right
 1	 1	 Date-	 Left
 2	 2	 Tv Prog+/Up	 Ch +
 3	 3	 Tv Prog-/Down	 Ch -
 4	 4	 '/''	 Dual
 5	 5	 Audio/Monitor	 Mute
 6	 6	 Tv/Video	 TV/R
 7	 7	 <<	 <<
 8	 8	 Play	 Play
 9	 9	 >>	 >>
 0	 0	 Rec	 Rec





Originale	Sostituto	Originale	Sostituto
Stop	Stop		
Pause	Pause		
Scene Finder	3D		
Prog Check	Menu		
Prog	Sleep		
OK	Ok		
>>I/Push Jog+	>>I		
I<</Push Jog-	I<<		

